Technical Notes

Serial communication

Update:24.06.2021




Pin	Description
1	RxD
2	TxD
3	GND, Ground
4	Battery +
5	CAN Low
6	CAN High


The SIO-commands can be used for serial communication with the EFOY fuel cell via a Terminal program.
For example: Terminal 2014, v.1.39b – provided by SFC

Required components:

Interface Adapter IA1	151 075 011
USB Adapter	151 906 018
Data Cable RJ-45 / RJ-12	158 906 008 (in urgent cases a cable RJ-12 / RJ-12 can also be used)
Windows PC	With installed terminal program, example: Terminal 2014

1. Connect the EFOY fuel cell to a windows PC by using the EFOY Interface Adapter IA1, USB Adapter and data cable
2. Connect the RJ-12 connector into the plug nr. 8 on the fuel cell.
3. Open the Terminal and follow the instructions in the PDF





SFC Energy AG
Eugen-Sänger-Ring 7
85649 Brunnthal · Germany

Tel: +49 89 673 592 0
Email: info@sfc.com
www.sfc.com

MADE BY SFC ENERGY